



Lambda Sensor Tester

- Handheld, user friendly, simple and easy to use

Overview

The SP Diagnostics lambda sensor tester checks the operation of the lambda switch whilst still on the vehicle. It can be used in conjunction with a gas analyser to check air / fuel ratios.

Specification

Display / Input:

- Simple LED indication of sensor condition

Contents

- Lambda Sensor Tester
- Cable PierceProbe
- Instruction Sheet